

VME BPM - Necessary Maintenance #15293

Replace SBC at F4

01/24/2017 11:02 AM - John Diamond

Status:	Resolved	Start date:	01/24/2017
Priority:	Normal	Due date:	
Assignee:	John Diamond	% Done:	100%
Category:		Estimated time:	2.00 hours
Target version:		Spent time:	0.00 hour
Description			
sbpmf4 does not boot. Replace the SBC with a spare.			

History

#1 - 01/24/2017 11:06 AM - John Diamond

Boot configuration for sbpmf4:

```
boot device      : dc0
processor number : 0
host name       : fecode-bd
file name       : vxworks_boot/kernel/mv2400/v5_5/vxWorks
inet on ethernet (e) : 131.225.127.116:ffffff00
inet on backplane (b):
host inet (h)    : 131.225.121.145
gateway inet (g) : 131.225.127.200
user (u)        : vxworks_boot
ftp password (pw) (blank = use rsh):
flags (f)       : 0x0
target name (tn) : sbpmf4_0xc1b
startup script (s) : vxworks_boot/fe/sbpmf4/sbpmf4startup
other (o)       :
```

#2 - 01/24/2017 02:05 PM - John Diamond

- Status changed from New to Resolved

- % Done changed from 0 to 100

Replacement wasn't necessary - suspect short.