

## VME Intensity Monitor - Task #16045

### Configure a cycle device for R:TOR703 g-2 operation

04/03/2017 10:36 AM - John Diamond

<b>Status:</b>	Resolved	<b>Start date:</b>	04/03/2017
<b>Priority:</b>	Normal	<b>Due date:</b>	
<b>Assignee:</b>	John Diamond	<b>% Done:</b>	100%
<b>Category:</b>	Deploy & Config	<b>Estimated time:</b>	2.00 hours
<b>Target version:</b>		<b>Spent time:</b>	2.00 hours
<b>Description</b>			
Configure a cycle device that measures each micro-bunch injection for g-2 operation.			

#### History

##### #1 - 04/03/2017 10:39 AM - John Diamond

Our last e-mail to the Muon department suggested that the device be called R:T703lx (where x comes from the recycler reset TCLK event).

##### #2 - 04/03/2017 10:51 AM - John Diamond

- Subject changed from *Configure a cycle device for R:TOR753 g-2 operation* to *Configure a cycle device for R:TOR703 g-2 operation*

##### #3 - 04/03/2017 01:54 PM - John Diamond

- Status changed from *New* to *Resolved*

- % Done changed from *0* to *100*

Configured a cycle device with 8 events called R:T703E9 and an injection cycle device triggered on the \$F6 called R:T703I9.

Found that the CycleDevice class has a hard-limit of 6 samples. Increased this to 32.

Unfortunately the cycle device support as it stands has no way of supporting two different samples with the same TCLK event like the g-2 transfers are structured. We will need to come up with a way to support the second group of 8 transfers. I will create another ticket for this.

##### #4 - 04/03/2017 01:59 PM - John Diamond

See [#16050](#) for supporting the second group of 8 transfers.