

uBoone Operations - Issues

#	Tracker	Status	Priority	Subject	Assignee	Updated
9206	Necessary Maintenance	Closed	Normal	Adjust PMT HV supply monitoring ranges	Glenn Horton-Smith	10/02/2015 02:59 PM
9003	Necessary Maintenance	Closed	Normal	Write interface code		10/15/2015 02:27 PM
9001	Necessary Maintenance	Closed	Normal	Write EDR		10/15/2015 02:29 PM
8760	Necessary Maintenance	Closed	Normal	Re-label TPC warm cables	Anne Schukraft	10/15/2015 02:28 PM
8751	Necessary Maintenance	Closed	Normal	Connections to downstream purity monitor and purity monitor rack 1	Ben Carls	02/08/2016 10:36 AM
8750	Necessary Maintenance	Closed	Normal	Connections to upstream purity monitor and purity monitor rack 2	Ben Carls	02/08/2016 10:35 AM
8749	Necessary Maintenance	Closed	Normal	Controlled access to drift HV rack	Sarah Lockwitz	05/18/2015 10:35 AM
8733	Necessary Maintenance	Closed	Normal	Update mapping documentation to reflect spare HDMI cable used	Anne Schukraft	07/10/2015 11:45 AM
8732	Necessary Maintenance	Closed	Normal	Correct Mapping Document (DocDB-3092) to reflect system as installed	Anne Schukraft	05/14/2015 02:32 PM
8730	Necessary Maintenance	Closed	Normal	Write up purity monitor rack power down procedure	Ben Carls	02/08/2016 10:36 AM
8729	Necessary Maintenance	Closed	Normal	Write procedure to power down laser rack	Thomas Strauss	05/18/2015 10:30 AM
8727	Necessary Maintenance	Closed	Normal	Add slowmon archiving of laser, purity monitor, and TPC HV	Glenn Horton-Smith	10/02/2015 02:41 PM
8720	Necessary Maintenance	Closed	Normal	Repeat drift HV commissioning tests at LArTF	Sarah Lockwitz	10/15/2015 02:33 PM
8367	Necessary Maintenance	Closed	Urgent	Add and archive channels for feedthrough temperatures, heaters	Glenn Horton-Smith	05/17/2015 07:59 PM
8152	Necessary Maintenance	Closed	Normal	review daq, pc status, and related alarm ranges		10/02/2015 08:01 PM
8151	Necessary Maintenance	Closed	Normal	review all crate temperature and fan speed alarm ranges		10/02/2015 08:01 PM
8150	Necessary Maintenance	Closed	Normal	review all our power supply alarm ranges		10/02/2015 08:00 PM
8149	Necessary Maintenance	Closed	Normal	review all our read-only cryogenics status alert ranges	Glenn Horton-Smith	10/02/2015 03:07 PM
8140	Necessary Maintenance	Closed	Normal	review all slowmoncon alarms	Glenn Horton-Smith	10/02/2015 08:04 PM
7866	Necessary Maintenance	Closed	Normal	Check on TPC R4 fanpack	Glenn Horton-Smith	03/21/2015 02:48 PM
7706	Necessary Maintenance	Closed	Normal	Measure, make, and connect cables between purity monitor racks and Liz	Ben Carls	05/14/2015 02:32 PM
7705	Necessary Maintenance	Closed	Normal	Check out the PMT HV outputs and set points.	Matthew Toups	05/14/2015 02:31 PM
7703	Necessary Maintenance	Closed	Normal	Repair LAr liquid level probes		05/14/2015 02:31 PM
7702	Necessary Maintenance	Closed	Normal	Investigate Glassman current monitoring precision		05/14/2015 02:31 PM
7701	Necessary Maintenance	Closed	Normal	Bring SHV-terminated cable for voltage pick-off to platform	Anne Schukraft	05/14/2015 02:30 PM
7699	Necessary Maintenance	Closed	Normal	Check out the LAr level - drift_HV interlock		05/14/2015 02:30 PM
7698	Necessary Maintenance	Closed	Normal	Order spare Wiener power supply brick	Bruce Baller	05/14/2015 02:30 PM
7697	Necessary Maintenance	Closed	Normal	Test and replace Wiener power supply brick	Sowjanya Gollapinni	05/14/2015 02:29 PM
7696	Necessary Maintenance	Closed	Normal	Check out and test laser-PMT-drift HV interlock box		05/27/2015 10:07 AM
7551	Necessary Maintenance	Closed	Normal	Check temperature probe #2 in LASER-1 rack	Thomas Strauss	03/21/2015 02:49 PM